


ASSEMBLY INSTRUCTIONS





Dining Chair




REPLACEMENT PARTS

Please do not contact the company purchased from as we can help you faster.

Order replacement parts and hardware at "boltonfurniture.com"

 . Use of power tool to assemble this product will invalidate any claim and damage this product making it unsafe!!! . Please assemble on a clean soft surface to avoid damage.	 +  20 minutes	<u>Tool Required</u>  (Not included)  (Included)
--	--	---

Dining Chair



Identifying the hardware-Identify the hardware using the illustrations below.

F  **02**
1/4"x20x45 mm

G  **02**
1/4"xØ10Dx1.5mm

H  **02**
1/4"xØ16 Dx1.5mm

J  **04**
5/16"x18x75 mm

K  **04**
5/16"x18x 50mm


L  **08**
5/16"xØ11Dx1.5mm

M  **08**
5/16"xØ19Dx1.5mm


N  **01**
ALLEN WRENCH

P  **06**
4.0x38mm


Step 1



Step 2



Step 3



Step 4

